




Tandem Sport Target Challenger



Assembly

Step 1

Insert the Short Bar (2) into the hole of the Extend Bar (1) with Washer (9) & Bolt (10). Fix the Cross Bar (A) & Extend Bar (1) with two Washers (9) & Bolts (10), then slide the Weight Plate (3) onto the Short Bar (2). Assemble bracket of the Upright Support (4) onto the Cross Bar (A) and Extend Bar (2) with four Washers (9) and Bolts (10) as shown in Figure A.




Step 2

Insert the Upright (23) into the top of the Inner Adjustable Bar (6) with two M6by30 Bolts (21) and M6 Nuts (22) first. Fix the Spring (20) and Arm O Frame Nut (19) with Knob (16) and Safety Nut (15). Fix the O Frame (7) with two M6by30 Bolts (21) and M6 Nuts (22) as shown in Figure B.

Adjustments

Height: Loosen the Lock (13) and adjust the height of the Adjustable Bar (5) and Upper Adjustable Bar (6) first. After desired height is reached, tighten Knobs (13).
Angle: Turn up the handle of the Knob (16) and adjust the O Frame (7) to the desired angle. Re-close the handle of the Knob (16) as shown in Detail B.



PARTS LIST

No.	Description	Q'ty	No.	Description	Q'ty
1	Extend Bar	1	12	Round End Cap	1
A	Cross Bar	1	13	Knob	2
2	Short Bar	1	14	Wheel	2
3	Weight Plate	1	15	Safety Nut	1
4	Upright Support	1	16	Knob	1
5	Adjustable Bar	1	17	Bolt	2
6	Inner Adjustable Bar	1	18	Nut	2
7	"O" Frame	1	19	Arm O-Frame	1
8	Net	1	20	M6by30 Bolt	4
9	Flat Washer	2	21	M6 Nut	4
10	Bolt	2	23	Upright	1